

---

**Onan**

**Parts  
Manual**  
NHE/NHEL  
Emerald III  
**GenSet**



**RV Electric Generating Set**

**Onan Service Parts**

940-0228  
9-88 (Spec D, E)  
Replaces 12-87 (Spec D)  
Printed in U.S.A.

# HARDWARE IDENTIFICATION


Illustrated hardware items are only for identification purposes. All hardware items listed throughout this parts catalog are steel SAE grade five (5) or lower (zinc plated with clear chromate dip) unless parts description indicates differently. All dimensions are in inches.

## WASHER TYPES




\* - Flat washer dimensions given are: Inside Diameter (ID), Outside Diameter (OD) and Thickness (Thk).

## BOLT AND SCREW TYPES



L - Measure length between these points.

### INTERNAL DRIVE TYPES



## NUT TYPES



## Index

Adapter, Carburetor - LPG 27  
Adapter, Exhaust (Flange Type) 28,30  
Armature, Generator 32

Base, Oil 10  
Bearing, Camshaft 4  
Bearing, Crankshaft 4  
Block, Brush 32  
Block, Cylinder 4  
Block, Terminal 34  
Board, Circuit 34  
Box, Breaker 18,19  
Bracket, Exhaust 28,30  
Bracket, Governor 22  
Breaker, Circuit 34  
Brush, Generator 32

Carburetor, Gasoline 12  
Carburetor, LP 14  
Carburetor, Components (Gasoline) 17  
Carburetor Components (LP) 16  
Clamp, Muffler 28,30  
Clip, Retaining 22  
Coil, Ignition 18  
Control, Generator 34  
Control, Remote 36  
Cover, Breather 4  
Cover, Brush-Block 32  
Cover, Control 34  
Cover, Valve 4  
Crankshaft 6

Element, Air Cleaner 12,14

Filter, Breather Tube 4  
Filter, LPG 14  
Filter, Oil 9  
Flywheel 6  
Fuse, 5 Ampere 34

Gasket, Exhaust Manifold 28,30  
Gearcase 8  
Generator 32  
Guard, Scroll 24  
Guide, Valve 4

Hanger, Exhaust 28,30  
Harness, Wiring (Control To Engine) 34  
Harness, Wiring (Ignition Relay) 14  
Harness, Wiring-Remote 38  
Head, Cylinder 4  
Hose, Fuel 14  
Housing, Air 24

Housing, Air Cleaner 12,14  
Housing, Below Floor 26  
Housing, Choke 12  
Housing, Stator 32

Index, Numerical 41,42,43,44  
Isolator, Vibration-Eng/Gen 10

Kit, Carburetor Repair 17  
Kit, Gasket 4

Line, Fuel-Gasoline 12  
Line, Fuel-LP 14

Manifold, Exhaust 28,30  
Manifold, Intake 12,14  
Muffler, Spark Arrestor 28,30

Paint, Green 40  
Pan, Grip 10,26  
Panel, Housing 26  
Piston 4  
Plug, Spark 18  
Points, Ignition 19  
Pump, Fuel - Electric 12  
Pump, Oil 4

Regulator, LP 14,27  
Resistor, Fixed 32  
Ring, Piston 4  
Rod, Connecting 4  
Rod, Governor 22

Seal, Oil-Crankshaft 4,8  
Seat, Valve 4  
Shield, Noise 24  
Solenoid, Start 34  
Spring, Governor 22  
Starter 20  
Starter Components 21  
Stator, Generator 32  
Strap, Ground 10,24  
Strap, Muffler 28  
Switch, Pressure - Oil 9  
Switch, Rocker - Control 34

Tappet, Valve 4  
Tube, Breather 12,14  
Tube, Exhaust 28

Valve, Exhaust 4  
Valve, Intake 4  
Valve, Shut-off - Fuel(LP) 14